MODERN OPERATING SYSTEMS

LECTURE 4

AUTHOR: DR. ZVEREVA OLGA M.



AGENDA

- ➤ COMMANDS
 - ✓ COMMANDS WITH DIRECTORIES
 - ✓ COMMANDS WITH FILES
 - ✓ OTHER USEFUL COMMANDS
- > BATCH FILES
 - ✓ DEFINITION AND STRUCTURE
 - ✓ SPECIFIC COMMANDS
 - ✓ PARAMETERS
 - ✓ VARIABLES



MAIND PROMPT VVIINDOVV

Microsoft Windows [Version 10.0.17134.619]

C:\Windows\system32> 💂

(c) 2018 Microsoft Corporation. All rights reserved.

Current directory
as a prompt
(invitation to input
a command)

It is necessary to type a command here



COMMAND GENERAL SYNTAX

COMMAND_NAME PARAMETER1 PARAMETER2 ... /KEY1 /KEY2 ...


WHERE:

- COMMAND_NAME DETERMINE THE ACTION TO BE DONE (COPY, TYPE, MOVE, DELETE, AND ETC.)
- > PARAMETER THE OBJECT TO BE PROCESSED
- > KEY DETAILS HOW IT WILL BE DONE

WORKING WITH DIRECTORIES

DIRECTORY ==FOLDER

TO CHANGE CURRENT DIRECTORY





```
Administrator: Command Prompt

C:\Windows\system32>cd
C:\Windows\system32

C:\Windows\system32>cd \

C:\V
```

COMMAND "DIR"

```
Administrator: Command Prompt
                                                                                                                ×
C:\1>dir /?
Displays a list of files and subdirectories in a directory.
DIR [drive:][path][filename] [/A[[:]attributes]] [/B] [/C] [/D] [/L] [/N]
  [/O[[:]sortorder]] [/P] [/Q] [/R] [/S] [/T[[:]timefield]] [/W] [/X] [/4]
  [drive:][path][filename]
             Specifies drive, directory, and/or files to list.
             Displays files with specified attributes.
  attributes D Directories
                                           R Read-only files
              H Hidden files
                                           A Files ready for archiving
              S System files
                                           I Not content indexed files
              L Reparse Points

    Prefix meaning not

             Uses bare format (no heading information or summary).
  /B
  /c
             Display the thousand separator in file sizes. This is the
             default. Use /-C to disable display of separator.
             Same as wide but files are list sorted by column.
  /D
  /L
             Uses lowercase.
             New long list format where filenames are on the far right.
  /N
             List by files in sorted order.
              N By name (alphabetic)
                                         S By size (smallest first)
  sortorder
              E By extension (alphabetic) D By date/time (oldest first)
              G Group directories first - Prefix to reverse order
             Pauses after each screenful of information.
  /0
             Display the owner of the file.
             Display alternate data streams of the file.
  /R
  /S
             Displays files in specified directory and all subdirectories.
             Controls which time field displayed or used for sorting
             C Creation
  timefield
             A Last Access
             W Last Written
```

```
Administrator: Command Prompt
                                                                                                     X
                                            C:\WINDOWS\system32>dir *.log
C:\>dir /A /O:N
                                            Том в устройстве С не имеет метки.
Volume in drive C has no label.
                                            Серийный номер тома: 129В-FE90
 Volume Serial Number is 9E87-56B0
                                            Содержимое папки C:\WINDOWS\system32
Directory of C:\
                                           14.05.2018 11:49
                                                                        50 090 NetSetupMig.log
02/20/2019 02:50 AM
                        <DIR>
                                      $Recy
                                                                           50 090 байт
                                                          1 файлов
03/10/2019 07:38 AM
                        <DIR>
                                      1
                                                          0 папок 36 694 544 384 байт свободно
03/10/2019 07:47 AM
                        <DIR>
                                       2
03/10/2019 07:49 AM
                        <DIR>
03/06/2019 04:37 AM
                                      Config.Msi
                        <DIR>
02/20/2019 08:40 AM
                        <JUNCTION>
                                      Documents and Settings [C:\Users]
03/10/2019 02:26 AM
                        6,827,986,944 hiberfil.sys
02/20/2019 12:51 AM
                        <DIR>
                                       Intel
02/20/2019 01:20 AM
                        <DIR>
                                       MS0Cache
03/06/2019 04:37 AM
                        2,550,136,832 pagefile.sys
04/11/2018 04:38 PM
                                      PerfLogs
                        <DIR>
03/03/2019 01:06 AM
                                      Program Files
                        <DIR>
02/20/2019 01:33 AM
                                      Program Files (x86)
                        <DIR>
03/03/2019 01:23 AM
                        <DIR>
                                      ProgramData
02/20/2019 08:40 AM
                        <DIR>
                                      Recovery
03/06/2019 04:37 AM
                           16,777,216 swapfile.sys
                                      System Volume Information
03/08/2019 05:50 AM
                        <DIR>
02/20/2019 01:28 AM
                        <DIR>
                                      Users
02/20/2019 04:12 AM
                        <DIR>
                                       Windows
              3 File(s) 9,394,900,992 bytes
             16 Dir(s) 448,338,165,760 bytes free
```



OTHER DIRECTORY COMMANDS

- TREE GRAPHICALLY DISPLAYS THE DIRECTORY STRUCTURE OF A DRIVE OR PATH
- XCOPY COPIES FILES AND DIRECTORY TREES
- MKDIR (MD) CREATE NEW DIRECTORY
- RMDIR DELETE DIRECTORY

WORKING WITH FILES

```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.17134.619]
(c) 2018 Microsoft Corporation. All rights reserved.
C:\Windows\system32>CD \
C:\>COPY CON \2\3.TXT
text 3
       1 file(s) copied.
C:\>dir 2
 Volume in drive C has no label.
Volume Serial Number is 9E87-56B0
Directory of C:\2
03/10/2019 07:36 AM
                       <DIR>
03/10/2019 07:36 AM
                       <DIR>
03/10/2019 07:36 AM
                                    8 3.TXT
03/10/2019 07:06 AM
                                    6 t1.txt
03/10/2019 07:05 AM
                                    6 t2.txt
              3 File(s)
                                    20 bytes
              2 Dir(s) 448,370,315,264 bytes free
C:\>
```

```
×
Administrator: Command Prompt
C:\>cd \1
C:\1>copy \2\3.txt
       1 file(s) copied.
C:\1>dir
Volume in drive C has no label.
Volume Serial Number is 9E87-56B0
Directory of C:\1
03/10/2019 07:38 AM
                       <DIR>
03/10/2019 07:38 AM
                       <DIR>
                                    8 3.TXT
03/10/2019 07:36 AM
03/10/2019 07:06 AM
                                    6 t1.txt
              2 File(s)
                                    14 bytes
              2 Dir(s) 448,370,061,312 bytes free
C:\1>
```

```
Administrator: Command Prompt
                                                                                                                               Microsoft Windows [Version 10.0.17134.619]
(c) 2018 Microsoft Corporation. All rights reserved.
C:\Windows\system32>cd \2
C:\2>type t1.txt
text 1
C:\2>type t2.txt
text 2
C:\2>type t3.txt
text 3
C:\2>copy t1.txt+t2.txt+t3.txt t_sum.txt
t1.txt
t2.txt
t3.TXT
        1 file(s) copied.
C:\2>type t_sum.txt
text 1text 2text 3
C:\2>
```

XCOPY

```
Administrator: Command Prompt
                                                                                                                                             C:\1>xcopy /?
Copies files and directory trees.
XCOPY source [destination] [/A | /M] [/D[:date]] [/P] [/S [/E]] [/V] [/W]
                            [/C] [/I] [/Q] [/F] [/L] [/G] [/H] [/R] [/T] [/U] [/K] [/N] [/O] [/X] [/Y] [/-Y] [/Z] [/B] [/J] [/EXCLUDE:file1[+file2][+file3]...]
               Specifies the file(s) to copy.
  source
  destination Specifies the location and/or name of new files.
               Copies only files with the archive attribute set,
               doesn't change the attribute.
               Copies only files with the archive attribute set,
  /M
               turns off the archive attribute.
               Copies files changed on or after the specified date.
  /D:m-d-y
               If no date is given, copies only those files whose
               source time is newer than the destination time.
  /EXCLUDE:file1[+file2][+file3]...
               Specifies a list of files containing strings. Each string
               should be in a separate line in the files. When any of the
               strings match any part of the absolute path of the file to be
               copied, that file will be excluded from being copied. For
               example, specifying a string like \obj\ or .obj will exclude
               all files underneath the directory obj or all files with the
                .obj extension respectively.
  /P
               Prompts you before creating each destination file.
  /5
               Copies directories and subdirectories except empty ones.
  /E
               Copies directories and subdirectories, including empty ones.
               Same as /S /E. May be used to modify /T.
               Verifies the size of each new file.
  /V
  /W
               Prompts you to press a key before copying.
  /C
               Continues copying even if errors occur.
```

XCOPY

```
Administrator: Command Prompt
C:\>xcopy \2\* \3\4\5
Does 3\4\5 specify a file name
or directory name on the target
(F = file, D = directory)? d
\2\t1.txt
\2\t2.txt
\2\t3.TXT
\2\t sum.txt
4 File(s) copied
C:\>dir \3\4\5
Volume in drive C has no label.
Volume Serial Number is 9E87-56B0
Directory of C:\3\4\5
03/10/2019 07:49 AM
                       <DIR>
03/10/2019 07:49 AM
                       <DIR>
03/10/2019 07:44 AM
                                    6 t1.txt
03/10/2019 07:05 AM
                                    6 t2.txt
03/10/2019 07:36 AM
                                    8 t3.TXT
03/10/2019 07:47 AM
                                   21 t_sum.txt
                                    41 bytes
              4 File(s)
              2 Dir(s) 448,372,637,696 bytes free
C:\>
```

TO SHOW AND CHANGE FILE ATTRIBUTES

THERE ARE 4 STANDARD FILE ATTRIBUTES:

- H "HIDDEN" (IT IS NOT INCLUDED IN AN ORDINARY DIRECTORY LISTING)
- R "READ ONLY" (COULDN'T BE CHANGED OR DELETED)
- A "ARCHIVE" (HAS TO BE ARCHIVED BY BUILT-IN ARCHIVING PROGRAM)
- S —"SYSTEM" (A FILE OR DIRECTORY THAT THE OPERATING SYSTEM USES A PART OF, OR USES EXCLUSIVELY)

"ATTRIB" COMMAND

```
Administrator: Command Prompt
                                                                                                                   C:\>attrib /?
Displays or changes file attributes.
ATTRIB [+R | -R] [+A | -A] [+S | -S] [+H | -H] [+O | -O] [+I | -I] [+X | -X] [+P | -P] [+U | -U]
[drive:][path][filename] [/S [/D]] [/L]
  + Sets an attribute.
  - Clears an attribute.
    Read-only file attribute.
    Archive file attribute.
    System file attribute.
    Hidden file attribute.
  O Offline attribute.
 I Not content indexed file attribute.
 X No scrub file attribute.
 V Integrity attribute.
 P Pinned attribute.
 U Unpinned attribute.
  B SMR Blob attribute.
  [drive:][path][filename]
      Specifies a file or files for attrib to process.
  /S Processes matching files in the current folder
      and all subfolders.
  /D Processes folders as well.
  /L Work on the attributes of the Symbolic Link versus
      the target of the Symbolic Link
```



"ATTRIB" COMMAND

```
Administrator: Command Prompt

C:\1>attrib t1.txt

C:\1>attrib +h t1.txt

C:\1>attrib t1.txt

C:\1>attrib t1.txt

C:\1>attrib t1.txt
```


OTHER FILE COMMANDS


- ➤ DEL DELETES FILE OR FILES
- FC COMPARES TWO FILES OR SETS OF FILES, AND DISPLAYS THE DIFFERENCES BETWEEN THEM
- FIND SEARCHES FOR A TEXT STRING IN A FILE OR FILES
- MOVE MOVES FILE(S) FROM ONE DIRECTORY INTO ANOTHER (REGISTER FILE IN ANOTHER DIRECTORY)
- MORE DISPLAYS OUTPUT ONE SCREEN AT A TIME
- > RENAME RENAMES A FILE OR FILES
- > TYPE -DISPLAYS THE CONTENTS OF A TEXT FILE

SOME OTHER USEFUL COMMANDS

- DATE DISPLAYS OR SETS THE DATE
- ECHO DISPLAYS MESSAGES, OR TURNS COMMAND ECHOING ON OR OFF
- FOR RUNS A SPECIFIED COMMAND FOR EACH FILE IN A SET OF FILES (CYCLE)
- PATH DISPLAYS OR SETS A SEARCH PATH FOR EXECUTABLE FILES.
- PROMPT CHANGES THE WINDOWS COMMAND PROMPT
- SET DISPLAYS, SETS, OR REMOVES WINDOWS ENVIRONMENT VARIABLES
- SHUTDOWN ALLOWS PROPER LOCAL OR REMOTE SHUTDOWN OF MACHINE
- START STARTS A SEPARATE WINDOW TO RUN A SPECIFIED PROGRAM OR COMMAND
- SYSTEMINFO DISPLAYS MACHINE SPECIFIC PROPERTIES AND CONFIGURATION
- TASKLIST DISPLAYS ALL CURRENTLY RUNNING TASKS INCLUDING SERVICES

Administrator: Command Prompt × C:\Windows\system32>systeminfo Host Name: DESKTOP-IV1039D OS Name: Microsoft Windows 10 Pro OS Version: 10.0.17134 N/A Build 17134 OS Manufacturer: Microsoft Corporation OS Configuration: Standalone Workstation OS Build Type: Multiprocessor Free Registered Owner: admin Registered Organization: Product ID: 00331-10000-00001-AA794 Original Install Date: 2/20/2019, 8:40:19 AM System Boot Time: 3/6/2019, 4:37:40 AM System Manufacturer: System Model: HP ProBook 470 G5 System Type: x64-based PC 1 Processor(s) Installed. Processor(s): [01]: Intel64 Family 6 Model 142 Stepping 10 GenuineIntel ~1792 Mhz HP Q85 Ver. 01.01.07, 10/17/2017 BIOS Version: C:\Windows Windows Directory: System Directory: C:\Windows\system32 Boot Device: \Device\HarddiskVolume2 System Locale: en-us; English (United States) Input Locale: en-us; English (United States) Time Zone: (UTC-07:00) Arizona Total Physical Memory: 16,279 MB Available Physical Memory: 12,281 MB Virtual Memory: Max Size: 18,711 MB Virtual Memory: Available: 14,821 MB Virtual Memory: In Use: 3,890 MB Page File Location(s): C:\pagefile.sys Domain: WORKGROUP Logon Server: \\DESKTOP-IV1039D Hotfix(s): 6 Hotfix(s) Installed. [01]: KB4100347 [02]: KB4103729 [03]: KB4462930 [04]: KB4485449 [05]: KB4487038 [06]: KB4487029 4 NIC(s) Installed. Network Card(s): [01]: Realtek PCIe GBE Family Controller Connection Name: Ethernet Media disconnected Status: [02]: Intel(R) Dual Band Wireless-AC 8265 Connection Name: Wi-Fi







TASK

- 1. CREATE 2 DIRECTORIES IN THE ROOT DIRECTORY WITH NAMES: DIR1 AND DIR2
- 2. BY MEANS OF INPUT FROM THE KEYBOARD, CREATE A NEW FILE WITH THE NAME OF "VERY USEFUL FILE" IN THE DIR1 DIRECTORY
- 3. COPY THIS FILE TO THE DIR2 DIRECTORY WITH THE NAME OF "CORRECTED FILE.TXT". OPEN IT IN A TEXT EDITOR (I.E. NOTEPAD) AND SLIGHTLY CHANGE ITS CONTENT.
- 4. COMPARE THESE TWO EARLIER CREATED FILES. HOW THEIR DIFFERENCES ARE PRESENTED IN THE WINDOW?
- 5. SET TO THE "CORRECTED FILE.TXT" THE ATTRIBUTE "READ ONLY".
- 6. CHECK WHAT IS THE WHOLE SET OF ATTRIBUTES FOR THIS FILE
- 7. TRY TO DELETE THIS FILE. IS THERE ANY PROBLEM?
- 8. DELETE ALL THE OBJECTS (DIR1, DIR2, AND BOTH FILES) HAVING BEEN CREATED FOR THIS TASK
- 9. DISPLAY THE CURRENT DATE AND CURRENT TIME. WRITE CURRENT DATE AND TIME INTO THE "FILE-DATE.DAT" FILE IN THE ROOT DIRECTORY.
- 10. MAKE SURE THAT THE "FILE-DATE.DAT" FILE CONTAINS THE NECESSARY DATA